**Figure 22** Blocks in Series


Figure 23 Blocks in Parallel

Figure 24 Modeling a Series and Parallel System in MEADEP

Block diagrams can only be drawn in one direction, starting from the source terminal and ending at the destination terminal.